TABLE CONNECTIONS FOR VARIOUS POWER SUPPLIES			
ARRGT.	POWER SUPPLY FOR MOTOR	D.C. FOR LOCAL CIRCUITS TO LINE RELAY AND SEL- ECTOR MAGNETS.	POWER CONNECTIONS
ı	IIO V. A.C. 50-60 CYCLES	RECT. CONTROL BY PTR. MTR. SWITCH	AS SHOWN
2	110 V. A.C. 50-60 CYCLES	RECTIFIER "ON" CONTINUOUSLY FOR UPPER CASE "H" OR "M" MOTOR CONTROL.	REMOVE WIRE FROM TERM. 3 ON RECEPTACLE "B" AND CONNECT TO TERM. I.
3	110 V. A.C. 50-60 CYCLES	NO V. D.C. POWER SUPPLY EXTERNAL TO TABLE (EITHER + OR - GROUNDED)	CONNECT A.C. TO RECEPTACLE "B" AS SHOWN. REMOVE WIRES FROM + AND - TERMINALS ON RECEPTACLE "D" AND TAPE ENDS. CONNECT + AND - IIO V. D.C. TO CORRESPONDING TERMS. OF RECEPTACLE "C."
4	IIO V. A.C. 25 CYCLES	RECTIFIER CONTROL BY PTR. MTR. SWITCH.	SAME AS ARRGT. I ABOVE EXCEPT ADD 99971 RESISTOR AS SPECIFIED IN NOTE "A" BELOW.
5	IIO V. A.C. 25 CYCLES	RECTIFIER "ON" CONTINUOUSLY FOR UPPER CASE "H" OR "M" MOTOR CONTROL.	SAME AS ARRGT. 2 ABOVE EXCEPT ADD 99971 RESISTOR AS SPECIFIED IN NOTE "A" BELOW.
6	110 V. A. C. 25 CYCLES	IIO V. D. C. POWER SUPPLY EXTERNAL TO TABLE (EITHER + OR- GROUNDED)	SAME AS ARRĜT. 3 ABOVE EXCEPT ADD 9997I RESISTOR AS SPECIFIED IN NOTE "A" BELOW.
7	110 V.D.C. POWER SUPPLY EXTERNAL TO TABLE (+ GROUNDED)		95050 CORD NOT USED. STRAP PTR. TERMS. 22 & 25. STRAP PTR. TERMS. 23 & 24.
8	HO V. D.C. POWER SUPPLY EXTERNAL TO TABLE (- GROUNDED)		95050 CORD NOT USED. STRAP PTR. TERMS. 22 & 24. STRAP PTR. TERMS. 23 & 25.

RTTY ELECTRONICS
TELETYPE=Sales-Service-Parts
PO Box 20101 El Sobrante, Ca.
94820. (510)222-3102
mr\_rtty@pacbell.net

## NOTES:

A. REMOVE AND DISCARD THE STRAP CONNECTED BETWEEN THE UPPER TERMINAL OF RECEPTACLE "A" AND TERMINAL "2 OF RECEPTACLE "B". REMOVE GROUND LEAD FROM THE LATTER TERMINAL. CONNECT A LEAD FROM 99971 RESISTOR TO TERMINAL"2 OF RECEPTACLE "B", AND CONNECT OTHER RESISTOR LEAD AND GROUND LEAD TO UPPER TERMINAL OF RECEPTACLE "A".

